Coils for HSX using FOCUS

Thanks to Aaron Bader, Caoxiang Zhu, Luquant Singh, Joseph Talmadge, and David Anderson




Overview

- Filamentary coils
- Targeting HSX vacuum fields


•
$$B_{normal} = \sum \frac{1}{2} \left(\frac{B \cdot n}{|B|} \right)^2$$

- Goals
 - Decrease B_{normal}
 - Decrease coil ripple
 - Decrease coil complexity (compared to HSX coils)


12 Modular




FOCUS Coils Minimum Coil to Plasma Distance 13.7 cm Minimum Coil to Coil Distance 8.3 cm Minimum Radius of Curvature 5.2 cm **Bnormal Error** 2.30e-5 **Actual Coils** Minimum Coil to Plasma Distance 14.4 cm Minimum Coil to Coil Distance 9.3 cm Minimum Radius of Curvature 8.1 cm **Bnormal Error** 1.37e-4



Comparison of Normal Magnetic Field




Unequally Spaced Coils




Middle 6 coils carry 100 kA First 3 and last 3 coils carry 200 kA

Corner coils have a 16% increase in coil to plasma separation as compared to HSX corner coils



Larger Corner Coils




FOCUS Coils

Minimum Coil to Plasma Distance 13.3 cm
Minimum Coil to Coil Distance 6.0 cm
Minimum Radius of Curvature 2.6 cm
Bnormal Error 1.76e-4

Actual Coils


Minimum Coil to Plasma Distance 14.4 cm
Minimum Coil to Coil Distance 9.3 cm
Minimum Radius of Curvature 8.1 cm
Bnormal Error 1.37e-4

Coils carry 152 kA of current except corner coils which carry 575 kA




1.37e-4

Hybrid: Helical L=1 m=5, 10 Modular



Minimum Coil to Plasma Distance
Minimum Coil to Coil Distance
Minimum Radius of Curvature
Second Min Radius of Curvature
Bnormal Error
Actual Coils
Minimum Coil to Plasma Distance
Minimum Coil to Coil Distance
Minimum Radius of Curvature
9.3 cm
Minimum Radius of Curvature
8.1 cm

All coils carry 120 kA of current, HSX coils carry 150 kA



Extra Slides

